



- 01 - Vin +44V
- 02 - Tempo OUT (CR)
- 03 - Speed X1 OUT (X1)
- 04 - GAS OUT (gas controller)
- 05 - GAS IN (gas throttle)
- 06 - Speed X2 OUT (X2)
- 07 - THEFT OUT (TB)
- 08 - nc
- 09 - HALL IN
- 10 - ebake IN
- 11 - Schalter 1
- 12 - PAS GND
- 13 - nc
- 14 - PAS signal
- 15 - Schalter 2
- 16 - nc
- 17 - nc
- 18 - PAS +5V
- 19 - speed 1
- 20 - speed 2